



# INNOVATION INN3

TRUE WIRELESS BLUETOOTH EARBUDS

## USER MANUAL

### XPOWER INN3:

Thank you for choosing XPower INN3 Bluetooth Earbuds. This manual will help you operate the Earbuds, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Earbuds. Please enjoy your time with our product.

### SAFETY RULES:

1. Please follow the rules described in this manual closely to ensure your safety. Before using this Stereo Earbuds, we would strongly encourage you to read through this user manual.
2. Please be care of any edges, uneven surfaces, metal parts accessories and its packaging so as to prevent any possible injury or damage.
3. Do not modify, repair or dismantle this Bluetooth Stereo Earbuds. Doing so may result in fires, electric shocks, complete breakdown of this Sport Bluetooth Stereo Earbuds, etc. All of which, are not covered under warranty.
4. Do not use any diluents or volatile liquid to clean the Sport Bluetooth Stereo Earbuds.
5. Do not use the Sport Bluetooth Stereo Earbuds in a hazardous location.
6. This product contains a built-in lithium battery, do not expose to strong sunshine, fire, or even throw into the fire to avoid explosion. Please dispose the battery base on local regulations.

### PACKAGE CONTENTS

INN3 Earbuds:



Charging case:



Micro USB cable:




Ear plug(L/M/S):



### GRAPHICAL REPRESENTATION :

1. Multifunction button
2. Microphone and LED indicator
3. Ear Tips
4. Magnetic Charging Bar
5. USB input
6. Charging LED indicator




### ADJUSTMENT

In order to get best audio performance, We suggest you try your suitable size of eartips from small to large. The correct seal in your ear to achieve optimal fit and stability.



In order to get better signal distance, please wear Earbuds as below pictures showed, Multifunction button round side towards to mouth direction.



### CHARGING

The bluetooth Earbuds and charging bar must be fully charged before first time to use.

1. Charge the Earbuds:

Magnetic connect recharging, the LED indicator will be solid red when charging, and will turn off when the earbuds fully charged. Charging bar can recharge two headphones simultaneously. The red indicator light will be off if it's fully charged.



Note:


1. When you playing the music, blue LED light flashed.
2. The red light will flash when the battery is low. To charging the power bank, use the usb cable to connect the adaptor or computer USB socket to charge the charging bar via 5VIA power current.

### SINGLE HEADSET OPERATING

1. Power on/off:

Power on: Long press the Multifunction button for about 4 seconds, the indicator light will flash blue.

Power off: Long press the Multifunction button for about 4 seconds, the indicator light will flash red.



2. Pairing: first time to use/repair

In power off status, long press the Multifunction button for 6 seconds, the indicator lights will flash red & blue alternately. Then turn on the Bluetooth function on your device and search "XPOWER INN3" and click connecting. Please enter "0000" if password is requested.

3. Once the headset is successfully paired and connected with your

device, you can use it to make a call and listen music.

4. Answer call / End call: Press the control button once to answer the incoming call. Press the control button once to end a call.
5. Reject call: Press the control button for 2 seconds to reject the incoming call.
6. Redial: Double press the control button to redial the last number you called on your phone.
7. Music: Press Multifunction button to pause music / play music.

## STEREO HEADSET OPERATION

### 1. Power on

Long press the Multifunction button for about 4 seconds, the indicator light flashes blue and you will hear a warning tone.


### 2. Power off: Power off one Earbuds only

Press and hold the Multifunction button for 4 seconds the LED will be flashing red and a notification sound will be heard accordingly, only need to power off one Earbuds, the other one will power off automatically if two Earbuds connected.

### 3. Pairing: first time to use

- In power off status, press and hold the Multifunction buttons of two Earbuds at the same time for 6 seconds, the red and blue LEDs will flash alternately, put two Earbuds close and you can find two "XPOWER INN3" in your phone.

Please do not click any one of them to pair.



- Two Earbuds will pair to each other automatically, after then one Earbuds blue LED flashes slowly, another Earbuds LED flashes red and blue alternately, this one is master Earbuds left channel, at this time you can see only one "XPOWER INN3" in your phone.

### 4. Search and connection

When master Earbuds flash red and blue alternately, Please wait several seconds until only one "XPOWER INN3" shows in your device then click to connect, input the code "0000" if needed.

Notice: Please do not click "XPOWER INN3" to connect before two Earbuds connected to each other. Otherwise the stereo function is not available.

### 5. Pairing successful

Master Earbuds LED flash blue slowly and slaver Earbuds flash blue two times after paired successfully, only one "XPOWER INN3" show in your phone it means connected already. (For the paired previously Earbuds and cellphone the Earbuds will connect automatically after you power on)

### 6. Calling

Only that Master Earbuds can hear the voice when calling and only the button of it can work.

Answer call/End call:

Press the control button once to answer the incoming call. Press the control button once to end a call.

Reject call:

Press the control button for 2 seconds to reject the incoming call.

Redial:

Double press the control button to redial the last number you called on your phone.

### 7. Play music

Play music Press any one of the Multifunction button once to play music.

Pause music Press any one of the multifunction button once to pause music.

## SPECIFICATIONS

Earbuds  
Battery: Button cell 55mAh  
Bluetooth Version: V4.1  
Working voltage: 3.2V-4.2V  
Microphones sensitivity: -40±2db  
Bluetooth frequency band: 2.4-2.48GHZ  
Bluetooth range: 10M  
Audio transmission protocols: A2DP/HFP/HSP/AVRCP

Charging Case  
Capacity: 250 mAh  
DC output voltage: DC5V  
DC output current (MAX): 1A  
DC charging voltage: DC5V  
DC charging current (MAX): 1A  
Product Certificate: FCC/CE/ROHS/BQB

## NOTICE

1. The mobile can not find the Earbuds if the INN3 is not paired. Please ensure the Earbuds is in pairing model before you search it. (red and blue lights flashing alternately)
2. If the Earbuds can not find any pairing device for five minutes, it will power off automatically.

## WARM TIPS

You must select a qualified adapter to charge this product.  
You must charge the bluetooth Earbuds if it has not been used for more than 3 months.

## WARNING

1. Do not put the product at the environment of too low or too high temperature for a long time, that may cause deformation, reduce the battery capacity, even shorten service lifetime.
2. Do not use the device when the thunderstorm coming, may cause a failure, and Increase the risk of struck by lightning.
3. Do not remove or modified Earbuds for any reason, otherwise may lead to Earbuds fault or burned, please send Earbuds to authorized service center for repairs.
4. Place the device and all accessories out of the reach of children and pets, small parts may be swallowed cause suffocation and serious consequences.
5. Do not put the Earbuds into the water.

## TROUBLESHOOTING

Phenomenon	Reason	Solution
Starting up failure	low battery	charge for the Earbuds
No sound after paired	wrong paired	re-pairing
Red light on during phone talking	low battery warning	please charge immediately
No indicator during charging	Earbuds didn't put into the charging cable well	check the Earbuds if it's well put into
Shut down automatically	low battery	charge for the Earbuds
Echo	volume is too high or environment is too noisy	adjust volume or change environment
Noise during phone calls	environment disturbance or earbuds is too far away from device	change environment or shorten the distance between headphone and device
Low volume of the caller	wrong wear of headphone	adjust headphone position
Signal is not well, interrupting	environment disturbance or headphone is too far away from device	far away from the interference signal or shorten the distance between headphone and device

## WARRANTY AND SUPPORT

For more products and supports, please visit our company website: [www.xpower.com.hk](http://www.xpower.com.hk)

The mentioned usage time may depend on the cellular network, location, signal, functional configuration, mobile device and other factors. Actual results may difference to theoretical value.



中文說明書請登入:  
For chinese version:

[www.xpower.com.hk](http://www.xpower.com.hk)